

Xerox® Mobile Scanner

When you're wireless, you're everywhere.

- Wireless 4GB Eye-Fi® card included
- Cordless no computer or cables required
- Rechargeable over 300 scans per charge
- Mobile device compatible







Anyone can use it. Everyone will want it.

We live in a fast paced world and want technology that can keep up with us. We have laptop computers so we can work anywhere. We have smartphones so we can reach out to friends and colleagues anytime. We don't want to be tethered to a desk with cords or to a wall for power. We want convenience and we want it to work without having to think about it. Well, get ready, because it is here.

A truly mobile device in every sense of the word, Xerox® Mobile Scanner gives you the power to take the information in your hand, right now, and share it with the world in seconds. The Xerox Mobile Scanner needs no cables or computer to operate. It talks to your PC, Android®, Mac®, iPhone®, iPad®, iPod® touch, or the cloud over Wi-Fi. It lets you send your document anywhere your mobile device will take you and it is as simple as the gesture of handing someone a piece of paper.

As consumers, we have a lot of paper in our lives. We also have a common desire to keep it organized and be able to easily find it and share it when needed. However many of us have been hesitant to try scanning it because of the fear that it will be complicated, difficult to manage and time consuming. We have changed all that.

The Xerox Mobile Scanner leaves traditional, tethered USB scanners and capture devices far behind.

Communicate when you want to, not when you can.

The Xerox Mobile Scanner is the first mobile, battery operated, cordless scanner that uses Wi-Fi to wirelessly transmit JPEG images and multipage PDF files from the scanner to any destination you want. Simply turn it on, select a file format (color PDF, back and white PDF or color JPG), and insert your document. With AutoLaunch technology, scanning begins as soon as documents are inserted into the scanner. A full page takes less than 10 seconds to scan and you can scan 300 pages before needing to recharge the battery.

Xerox Mobile Scanner can handle virtually any medium, including paper, plastic cards, business cards, receipts and photos. Your scanned items can be saved to the included Eye-Fi SD memory card or a USB flash drive. Setting up the Eye-Fi card to wirelessly transfer PDF and JPG images to your PC, Mac, Android, iPhone, iPad or the cloud is a breeze too.

It is time to discover the power of true wireless document sharing.



















Instantly, automatically, effortlessly wireless.

Eye-Fi® is the easiest way to organize and transmit anything that you scan. An SDHC memory card that has built-in Wi-Fi, it stores the images on your card and uses your wireless network to effortlessly transfer files to almost anywhere you want including online destinations such as Evernote®, Picasa®, Facebook®, Shutterfly® and MobileMe®.

Upon setup, specify which networks the Eye-Fi card uses to transfer your media. Add up to 32 networks for your card to use. The next time your scanner is on and within range of a specified network, your photos and documents will fly to your computer and to your favorite sharing site. During the quick set-up, you customize where you want your files sent. The Eye-Fi card will only send them to the device and to the sharing sites you choose.

Xerox® Mobile Scanner Product Specifications	
Model Number	XMobile
Scan Speed	10 seconds per page
Optical Resolution	300 dpi
Removable Media Support	SD card (4GB Eye-Fi Wireless Card included) and USB Flash Drive
Wi-Fi Support	802.11 b/g/n on 2.4GHz band (5GHz band not supported), Class 6
Wi-Fi Security	Static WEP 64/128, WPA-PSK, WPA2-PSK
Wi-Fi Direct Mode	Requires compatible Android or iOS devices
Mobile OS Support	Mobile apps available for Android and iOS
Computer OS Support	Windows® 8 / 7 / XP® (SP3)/Vista® and Macintosh OS X 10.5 +
Supported File Formats	JPG (color), multipage PDF (color and b&w)
Smartphone and Tablet Support	Supports mobile devices with media storage including Android®, Apple® iPad® and iPhone®, and Windows® smartphones
Maximum Document Size	8.5" x 14" (216 x 356 mm)
Minimum Document Size	2" x 2" (51 x 51 mm)
Scanning Media Supported	Paper, plastic ID cards, photos
Scanning Technology	CIS (contact image sensor) sensor, LED (light emitting diode) light source
Real Time Clock	YES for file creation date stamping
Airplane Mode	Turns off wireless radio while in flight
Bonus Software	PC Connect and Mac Connect scanner utilities, Nuance PaperPort & OmniPage Pro
Scans per charge	300 pages
Recharging Time	8 hours initial charge, ~4 hours recharge
Scanning Technology	Sensing Technology: CIS (Contact Image Sensor Light Source: LED (Light Emitting Diode)
Dimensions	11.5" (l) x 2.75" (w) x 2" (h) (293 x 70 x 51mm)
Weight	22.5 oz (638 g)

Transfer anywhere.

If you are away from your networks, simply set up Direct Mode. Scan photos or documents wherever you are — then when you're ready to transfer, just turn your scanner on and let Eye-Fi do the rest. The Eye-Fi card will create its own Wi-Fi network and transfer to the free iPhone/iPad or Android app. No matter where you are, you'll get your files on your device in no time. Then use your device's data connection (Wi-Fi, 3G or Edge) to share your content on-the-go—there's 25 sites to choose from. And if you prefer getting backed up and organized, automatically send those files to your computer at home.

Contents

- Mobile Scanner
- 4GB Eye-Fi SD memory card
- Carrying case
- Recharging/data cable and AC wall adapter
- Bonus software CD
- Cleaning and calibration sheets

To view a video of the Xerox Mobile Scanner scanner <u>click here</u>, or scan the QR code below with a smart phone



www.UniLinkinc.com

800.666.2980

Sales@UniLinkinc.com

©2015 Xerox Corporation. All rights reserved. Xerox® and Xerox and Design® are registered trademarks of Xerox Corporation in the United States and other countries and is used under license from Xerox Corporation. Visioneer is an authorised trademark licensee of Xerox®. Visioneer® OneTouch® and AutoLaunch™ are trademarks of Visioneer, Inc. Android is a trademark of Google Inc. Apple®, iPhone®, iPod® pred® and MobileMe® are trademarks of Apple Inc., registered in the U.S. and other countries. Microsoft®, SharePoint®, Windows Vista®, Windows®, the Windows logo and XP® are trademarks of Microsoft Corporation in the United States and/or other countries. iOS™ is a registered trademark of Cisco. Eye-Fi® is a trademark of Eye-Fi, Inc. Wi-Fi™ is a trademark of the Wi-Fi Alliance. Shutterfly is a service mark of Shutterfly, Inc. Picasa is a service mark of Google, Inc. Facebook is a trademark of Facebook, Inc. Evernote is a trademark of Evernote Corporation. Prices, features, specifications, capabilities, appearance and availability of Xerox products and services are subject to change without notice. 02/15
BR13738

